


Pneumatic Actuator

Operation & Service Manual

Models: 430084-88



Original Instructions

MANUAL NO.: 430084-88 REVISION: 04/2022



Unibloc Hygienic Technologies, LLC

1650 Airport Road NW, Suite 110 • Kennesaw, Georgia 30144 • USA

Tel 770-218-8900 E-Mail info@unibloctech.com

www.unibloctech.com

Information contained in this manual is subject to change without notice and does not represent a commitment on the part of Unibloc Hygienic Technologies, LLC. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of Unibloc Hygienic Technologies, LLC.

Copyright © 2022
Unibloc Hygienic Technologies, LLC
All Rights Reserved.

Revision Date: 04/2022
Manual No.: 430084-88

Table of Contents

Technical Specifications	4
Function	4
Versions	4
Material Data	4
Surface	4
Electrical and pneumatic connection	4
Control Air Specifications	4
Safety	5
Installation Instructions	5
General Information	5
Delivery Status	5
Mounting Guidelines	5
Assembly	5
Disassembly and Assembly Instructions	6
Disassembly: Air to Spring	6
Assembly: Air to Spring	9
Disassembly: Air to Air	13
Assembly: Air to Air	15
Spare Parts	19

Technical Specifications

Function

Air to Air: Air opened/ Air closed
Air to Spring: Air opened/ Spring Closed

Versions


- Female (see Figure 1)
- Male (see Figure 1)
- 6 bar
- 4 bar

Material Data

Sealing Elements	Nitrile
Stainless Steel Parts	304

Surface

Polished



Electrical and pneumatic connection

Electrical Connection

- ***WARNING*** Electrical work should only be performed by a trained professional.
- Check operating voltage and current specifications before connecting

Pneumatic Connection “P, R”

Connection	Use	Type
P (see Figure 1)	Control air connection	Thread R 1/8"
R (see Figure 1)	Return Vent	Thread R 1/8"

Control Air Specifications

Pressure	6 bar
Solids content	Max. particle size: 5 μm Max. particle volume: 5 mg/m^3
Water Content	Dew point: +2° C
Oil Content	Oil-free, max. volume: 25 mg/m^3 Oil

Safety



CAUTION: Air to Spring actuator assemblies are under heavy spring load and must be disassembled while using extreme caution. Failure to follow these instruction can result in injury. Any unauthorized changes to the valve may affect the proper functionality of the actuator and is not advised.

Installation Instructions

General Information

All maintenance and servicing should be performed by a trained technician.

Delivery Status

The drive is in the factory-tested state.

Mounting Guidelines

Installation Space:

Determine and define the connection axes before mounting.

Mounting:

Exclude tensile and compressive stress.


Assembly

Actuator should be assembled according to assembly instructions.


Disassembly and Assembly Instructions

Disassembly: Air to Spring


1. Clamp the casing (1) in a vise with aluminum (soft) jaws.
2. Unscrew the two lock nuts (23) and remove the valve and bracket assembly (24).




3. **CAUTION:** If the piston (10) is broken, the spring (15) will assist in pushing the top plate assembly (25) out of the casing (1). To avoid injury, make sure that no one stands in front or behind the actuator.
4. Unscrew the two flat head screws (4) and remove the flange (16).




5. Remove the top plate assembly (25) from the casing (1). (To aid in removal, it may be necessary to very carefully blow air into the "R" labeled terminal.




6. Remove the base plate/piston assembly (26) from the casing (1).




7. To remove the piston (10) from the assembly, we recommend using a lathe. Mount the shaft (17) on the lathe using soft chuck jaws and press the tailstock against the top of the piston (10). Compress the spring (15) with the tailstock enough to provide access to one of the axle (7) retaining rings (9).



8. Remove the retaining ring (9) and press the axle (7) through the shaft's axle bore (A) and piston's helical track (B).




9. Remove the track rollers (8) from the piston's helical track (B).




10. Relieve the spring's tension by backing off the tailstock completely.

11. Remove the piston (10) and spring (15). Then remove the baseplate assembly (27) from the chuck jaws.




12. Remove the shaft (17) from the base plate (22). The bushings (18,19) will come out on the shaft.




13. The actuator is now fully disassembled and ready for servicing.

Assembly: Air to Spring


1. Before assembling the actuator be sure to replace and lubricate o-rings (5,6,12,14) and seal (11). Ensure that all parts are cleaned and that no debris is left inside components.




2. Thoroughly grease the inside of the casing (1) and piston (10).



3. Install the bushings (18, 19) on the shaft (17). Replace shaft o-ring (20) and lubricate.




4. Insert the shaft (17) into the base plate (22).




5. We recommend using a lathe to aid in the following assembly steps.


6. Mount the shaft (17), with base plate (22) installed, on the lathe using soft chuck jaws and insert the piston (10) into the top of the spring (15). Place the bottom of the spring (15) against the top of the base plate (22) and press the tailstock spindle against the top of the piston (10).




7. Compress the spring (15) with the tailstock until the shaft (17) is inserted into the bore of the piston (10). Continue tensioning the spring until the shaft's axle bore (A) is aligned with the helical track (B) and is accessible for the installation of the axle assembly.




8. Mount retaining ring (9) onto one end of axle (7) and slide track roller (8) onto axle (7).



9. Insert axle (7), with track roller (8) installed, into helical slot (B) and through axle bore (A).




10. Slide the second track roller (8) onto the axle (7) and mount the second retaining ring (9).




11. Relieve the springs tension by backing off the tailstock completely and remove the base plate/piston assembly from the chuck jaws.


12. Slide the casing (1) over the piston (10) and onto the base plate (22).



13. Insert the guide bars (2,3) into the bores on top of the piston (10) and align them with the bores in the base plate (22).




14. Insert the flange (16) into the bottom of the base plate (22) and align the counter sunk holes with the bores in the base plate (22). While pressing down on the top plate (13) install and firmly tighten the flat head screws (4).



15. The actuator is now fully assembled.


16. Reinstall the valve and bracket assembly (24) and tighten the two lock nuts (23).




17. It is important to test the actuator to ensure that it is properly functioning before placing it back into service.

Disassembly: Air to Air


1. Clamp the casing (1) in a vise with aluminum jaws.
2. Unscrew the two lock nuts (23) and remove the valve and bracket assembly (24).




3. Unscrew the two flat head screws (4) and remove the flange (16).




4. Remove the top plate assembly (25) from the casing (1). (To aid in removal, it may be necessary to very carefully blow air into the "R" labeled terminal).




5. Remove the base plate/piston assembly (26) from the casing (1).




6. Remove the retaining ring (9) and press the axle (7) through the shaft's axle bore (A) and piston's helical track (B).




7. Remove the track rollers (8) from the piston's helical track (B).



8. Remove the piston (10) from the baseplate assembly (27).




9. Remove the shaft (17) from the base plate (22). The bushings (18,19) will come out on the shaft.




10. The actuator is now fully disassembled and ready for servicing.

Assembly: Air to Air


1. Before assembling the actuator be sure to replace and lubricate o-rings (5,6,12,14) and seal (11). Ensure that all parts are cleaned and that no debris is left inside components.




2. Thoroughly grease the inside of the casing (1) and piston (10).




3. Install the bushings (18, 19) on the shaft (17). Replace shaft o-ring (20) and lubricate.




4. Insert the shaft (17) into the base plate (22).




5. Insert the base plate assembly (27) into the piston (10).




6. Mount retaining ring (9) onto one end of axle (7) and slide track roller (8) onto axle (7).




7. Insert axle (7), with track roller (8) installed, into helical slot (B) and through axle bore (A).




8. Slide the second track roller (8) onto the axle (7) and mount the second retaining ring (9).




9. Slide the casing (1) over the piston (10) and onto the base plate (22).




10. Insert the guide bars (2,3) into the bores on top of the piston (10) and align them with the bores in the base plate (22).



11. Insert the flange (16) into the bottom of the base plate (22) and align the counter sunk holes with the bores in the base plate (22). While pressing down on the top plate (13) install and firmly tighten the flat head screws (4).




12. Reinstall the valve and bracket assembly (24) and tighten the two lock nuts (23).



13. It is important to test the actuator to ensure that it is properly functioning before placing it back into service.

ITEM NO.	PART NO.	DESCRIPTION	QTY.
1	430087-1	CASING	1
2	430087-2	GUIDING BAR	1
3	430087-3	GUIDING BAR	1
4*	430087-4	FLAT HEAD SCREW	2
5*	430087-5	O-RING	2
6*	430087-6	O-RING	2
7	430087-7	AXEL	1
8	430087-8	TRACK ROLLER	2
9*	430087-9	RETAINING RING	2
10	430087-10	PISTON	1
11*	430087-11	PKK1 SEAL	1
12*	430087-12	O-RING	2
13	430087-13	TOP PLATE	1
14*	430087-14	O-RING	1
16	430087-16	FLANGE	1
17	430087-17	SHAFT	1
18*	430087-18	BUSHING	1
19*	430087-19	BUSHING	1
20*	430087-20	O-RING	1
21*	430087-21	BOLT	2
22	430087-22	BASE PLATE	1

* ITEMS INCLUDED IN REPAIR KIT: 430087-KIT




THIS DRAWING AND ALL IDEAS INCORPORATED IN ITS DESIGN ARE THE EXCLUSIVE PROPERTY OF UNIBLOC. UNIBLOC, THE UNIBLOC LOGO, AND ALL IDEAS INCORPORATED IN ITS DESIGN ARE TRADEMARKS OF UNIBLOC. THIS DOCUMENT IS A CONFIDENTIAL DOCUMENT. IT IS NOT TO BE REPRODUCED, COPIED, OR DISTRIBUTED WITHOUT THE WRITTEN PERMISSION OF UNIBLOC. UNIBLOC TECHNOLOGIES, LLC.			
BY	DATE	DWG. TITLE	
KL	08/03/16	ACTUATOR PARTS:	
CHECKED		AIR TO AIR	
APP'D		SIZE	DWG. NO.
SCALE		430084-104	G430084
ALL DIMENSIONS IN MM. [IN]		RELEASE DATE	REV. NO.
		AUG. 3, 2016	0
		SHEET 1 OF 2	



ITEM NO.	PART NO.	DESCRIPTION	QTY.
1	430088-1	CASING	1
2	430088-2	GUIDING BAR	1
3	430088-3	GUIDING BAR	1
4*	430088-4	FLAT HEAD SCREW	2
5*	430088-5	O-RING	2
6*	430088-6	O-RING	2
7	430088-7	AXEL	1
8	430088-8	TRACK ROLLER	2
9*	430088-9	RETAINING RING	2
10	430088-10	PISTON	1
11*	430088-11	PK1 SEAL	1
12*	430088-12	O-RING	2
13	430088-13	TOP PLATE	1
14*	430088-14	O-RING	1
15	430088-15	SPRING	1
16	430088-16	FLANGE	1
17	430088-17	SHAFT	1
18*	430088-18	BUSHING	1
19*	430088-19	BUSHING	1
20*	430088-20	O-RING	1
21*	430088-21	BOLT	2
22	430088-22	BASE PLATE	1

* ITEMS INCLUDED IN REPAIR KIT: 430088-KIT




THIS DRAWING AND ALL IDEAS INCORPORATED IN ITS DESIGN IS THE EXCLUSIVE PROPERTY OF UNIBLOC. NO PART OF THIS DRAWING OR THE INFORMATION CONTAINED HEREIN IS TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITING OF UNIBLOC HYGIENIC TECHNOLOGIES, LLC.

UNIBLOC Hygienic Technologies		DWG. TITLE		ACTUATOR PARTS: AIR TO SPRING	
DRAWN	BY	DATE	SIZE	DWG. NO.	REV. NO.
CHECKED	KL	08/03/16			
APPD					
SCALE				430088-129	G430088
ALL DIMENSIONS IN MM. [IN]			RELEASE DATE	AUG. 3, 2016	SHEET 1 OF 2

ITEM NO.	PART NO.	DESCRIPTION	QTY.
1	430088-1	CASING	1
2	430088-2	GUIDING BAR	1
3	430088-3	GUIDING BAR	1
4*	430088-4	FLAT HEAD SCREW	2
5*	430088-5	O-RING	2
6*	430088-6	O-RING	2
7	430088-7	AXEL	1
8	430088-8	TRACK ROLLER	2
9*	430088-9	RETAINING RING	2
10	430088-10	PISTON	1
11*	430088-11	PKK1 SEAL	1
12*	430088-12	O-RING	2
13	430088-13	TOP PLATE	1
14*	430088-14	O-RING	1
16	430088-16	FLANGE	1
17	430088-17	SHAFT	1
18*	430088-18	BUSHING	1
19*	430088-19	BUSHING	1
20*	430088-20	O-RING	1
21*	430088-21	BOLT	2
22	430088-22	BASE PLATE	1

* ITEMS INCLUDED IN REPAIR KIT: 430088-KIT



THE DRAWING AND ALL DATA INCORPORATED IN THIS DOCUMENT ARE THE EXCLUSIVE PROPERTY OF UNIBLOC. NO PART OF THIS DOCUMENT IS TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF UNIBLOC TECHNOLOGIES LLC.			
BY	DATE	DWG. TITLE	
DRAWN	KL	ACTUATOR PARTS:	
CHECKED	08/03/16	AIR TO AIR	
APTD		SIZE	DWG. NO.
SCALE		430085-129	G430085
ALL DIMENSIONS IN MM. [IN]		RELEASE DATE	REV. NO.
		AUG. 3, 2016	0
		SHEET 1 OF 2	



Notes:

[illegible]

WARRANTY

Unibloc Hygienic Technologies, LLC ("Unibloc") warrants that its product will be free from defects in material and workmanship which results in noncompliance with the Specifications for such product. This warranty shall begin upon delivery and continue for a period of one (1) year from such date. If during this period the product does not comply with its specifications as a result of defects in material or workmanship, contact Unibloc to arrange return of the faulty product, shipping prepaid and fully insured, to an authorized Unibloc service facility. If upon inspection of the item in question, defects in workmanship or materials are revealed, Unibloc's sole obligation under this warranty shall be to supply a repair or replacement for any defective part of a product, and to return such product to the customer by shipping it EX WORKS (as defined in Incoterms 2020) the service facility. Unibloc shall not be required to supply any labor for repairs or replacement of parts. This warranty is void if the product has not been used as recommended or instructed, has been altered or used with unauthorized accessories, has been subject to misuse, abuse or accident, or has been damaged due to causes not related to poor workmanship or defective materials. All parts or components not manufactured by Unibloc are warranted only to the extent of the warranty of the respective manufacturers.

THIS LIMITED WARRANTY IS EXPRESSLY GIVEN IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT, ALL OF WHICH ARE HEREBY EXCLUDED. IN NO EVENT SHALL UNIBLOC OR ITS AFFILIATES BE LIABLE TO ANYONE FOR SPECIAL, COLLATERAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER ARISING IN CONTRACT OR IN TORT.

UNIBLOC RESERVES THE RIGHT TO MAKE TECHNICAL CHANGES WITHOUT NOTICE.



Unibloc Hygienic Technologies, LLC

1650 Airport Road NW, Suite 110 • Kennesaw, Georgia 30144 • USA

Tel 770-218-8900 E-Mail info@unibloctech.com

www.unibloctech.com